

Quick Start Guide



trio :) mini

Follow the easy steps shown inside to get your Trio Tablet up and running.

More Information

To find out more about your Trio Tablet and its cool features, check out the user manual on the Trio website:

www.triotablets.com/manuals

Click on:

Trio



Limited one year warranty

To contact our technical support team call:

844.400.8746

trio :)



recyclingourtablets.com

STEP 1: CHECK OUT THE CONTROLS


Before you do anything else, take a good look around your trio tablet and find out all the control buttons and other items of interest are.




STEP 2: CHARGE THE BATTERY

You need to charge up the battery before you use your trio tablet for the first time.

Connect the charger to your trio, using the USB/Charger cable. The cable plugs in to the USB/Charger Port at the side of your tablet.



The connection should look like this:



Connect USB cable into a charger (not supplied) or into a USB port on a computer. The screen will display a flashing battery symbol for a few seconds to show that the battery is charging. Keep the battery on charge for 6 to 8 hours to make sure that it is fully charged.

STEP 3: POWER UP

When the battery is fully charged, switch on your trio tablet. To do this, press and hold the power on/off button until the trio :) logo appears:



The logo remains until the startup step is finished; the startup screen then appears:



Touch the screen at the lock symbol and swipe sideways. This will unlock your tablet and display the desktop screen. At the bottom of the desktop screen you will see the following symbol:



Touch this symbol and the Apps screen appears. Touch any icon on the Apps screen and it opens the application that you have chosen. You are now up and running!

STEP 4: INSTALLING microSD card

1. Turn the tablet on its back and locate the notch at the bottom.
2. Use the notch to gently pry open the back cover and reveal the microSD slot.
3. Slide the metal lid of the microSD slot away from the edge of the tablet and then lift up.
4. Place the microSD card into the slot face up.
5. Close the metal lid and slide it towards the edge of the tablet to lock it.
6. Replace the back cover of the tablet.